

View this machine and more at:

https://www.thesewingstudio.co.uk







Features & Benefits

Top Features

- · Large sewing space 200mm
- Uniquely Designed Accessory Compartment
- Start/Stop function
- Sewing Guide
- More than 80 beautiful 7mm wide stitches
- 7 HUSQVARNA VIKING® original snap-on presser feet included
- Large assortment of HUSQVARNA VIKING® optional accessories
- Presser foot Recommendation-Button
- Speed Control







SEWING

200mm SEWING SPACE

Sew large quilts, home dec projects and garments easily.

 Large area to the right of the needle for wonderful ease of sewing.

START/STOP FUNCTION

- Sew without the foot control for easy, consistent speed.
- Press Start/Stop to begin and to stop sewing without using the foot pedal.
- Great for sewing rows of decorative stitches, sewing on buttons, making buttonholes and winding a bobbin.
- · Ideal for sewers with physical limitations.

SEWING GUIDE

 Easy to select the best stitch, stitch length, stitch width, thread tension, presser foot and presser foot pressure for the selected sewing technique and fabric.

82 BEAUTIFUL 7mm WIDE STITCHES

 Select from a wide variety of stitches for every technique and endless creative opportunities. You will always have the perfect stitch for every project.

LARGE ASSORTMENT OF OPTIONAL ACCESSORIES

 Many optional accessories for every sewing need and creative possibility. For all different types of sewing, quilting, home dec and more.

PRESSER FOOT RECOMMENDATION-BUTTON

 Shows the presser foot recommendation for the selected stitch on the LED display.

ONE-STEP BUTTONHOLES

- Buttonholes are quickly and easily sewn in a simple onestep process. Both columns are sewn in the same direction to lay smoothly and prevent distortion.
- Choose from five different styles for various sewing applications.

NEEDLE STOP UP/DOWN

• For easy pivoting, appliqué and more.

DROP FEED TEETH

 Easy to lower feed teeth at the back of the free arm for button sewing and free motion quilting.

FREE MOTION WITH ANY STITCH

 For easy quilting and beautiful free motion embroidery using any stitch you choose.

MIRROR IMAGE SIDE-TO-SIDE

• Flip stitches side-to-side for unlimited creative sewing.

29 NEEDLE POSITIONS

 Sews a straight stitch in 29 different needle positions for perfect topstitching, edge stitching, under stitching, stitching-in-the-ditch or quilting. Adjust and mirror the stitch length and width.

ADJUSTABLE PRESSER FOOT PRESSURE

• Sew any fabric weight and type with perfect results.

MACHINE

UNIQUELY DESIGNED ACCESSORY COMPARTMENT

- Modern, convenient and easily accessible storage for all the included accessories.
- The sleek modern compartment will look stylish when the sewing machine is not in use.

7 HUSQVARNA VIKING ORIGINAL SNAP-ON ACCESSORY FEET INCLUDED.

 A wide selection of easy snap-on presser feet are included with the HUSQVARNA VIKING® JADE™ 20 machine, including the One-Step Buttonhole foot.

SPEED CONTROL

• Easily adjust the sewing speed for greater control.

BUILT-IN NEEDLE THREADER

· Makes threading fast, easy and hassle free.

LED DISPLAY

• Chosen stitch is shown by number in the LED display.

BOBBIN WINDS FROM THE NEEDLE

 No need to unthread the machine when winding the bobbin.

LED LIGHTS

Reduces shadows while sewing.

 LED lights illuminate the needle area and sewing surface to make sewing easy and reduce eye strain.